

GUANGZHOU MICRON VENDING TECHNOLOGY CO., LTD.

2022 | User Manual

Click Youtube links to watch the videos

TOGETHER, LET'S STEP INTO THE NEW ERA OF UNMANNED RETAIL~






CONTENTS

Part I: Machine Hardware & System [Page 1~4]

Part II: Fast setup - 4 steps [Page 5~15]

- 2.1 Connect the machine to WIFI, or insert data SIM card. [Page 5~11]
- 2.2 Create product data base in the system. [Page 12~13]
- 2.3 Machine product set up. [Page 14]
- 2.4 Fill the machine. [Page 15]







CONTENTS

Part III: Machine basic settings [Page 16~30]

- 3.1 How to set cooling temperature with temp. controller [Page 16]
- 3.2 How to set currency symbol of selling price & set payment system [Page 17~20]
- 3.3 How to set the time of entering advertisement page [Page 21~23]
- 3.4 How to hide status bar [Page 24~25]
- 3.5 How to save coins to the coin machine [Page 26]
- 3.6 How to check the balance amount of coins [Page 27]
- 3.7 How to amend the Capacity of goods trays [Page 28]
- 3.8 How to set product shelf life date (Expiration) & warning[Page 29~30]





CONTENTS

Part IV: Features dictionary [Page 31~61]

- 4.1 How to upload Advertisement [Page 31~35]
- 4.2 How to upload LOGO/Service Tel. to the machine/server [Page 36~38]
- 4.3 How to edit Machine info. [Page 39~41]
- 4.4 How to set Sub account for your team members [Page 42~45]
- 4.5 How to set Sub account for your customers [Page 46~49]
- 4.6 How to use Member manage [Page 50~52]
- 4.7 How to check Real time inventory [Page 53~54]
- 4.8 How to check Orders & Sales Data [Page 55~57]
- 4.9 How to check Replenish record [Page 58~61]

Part V: Machine installation [Page 62~68]



Part I: Machine introduction





♦Goods Tray Option

- > Spiral racks
- Direct Push
- Conveyor belt

♦Payment System Option


- > Bill validator
- Coin mech
- Card reader
- E-wallet(upon availability)

♦Smart Vending System

□ Optional features:

- Elevator
- > Infrared drop sensor
- > Receipt printer





Model#: WM0-W

- ※ 5" LCD screen + Keypad
- Internet: WIFI/3G, 4G SIM Card
- **X** Android OS 5.1
- **X** ROM 8G / RAM 2G
- X Standard protocol: MDB/RS232
- X Standard variety: 6 Floors * 9 Slots
- Extra storage shelves
- × 2-Layer tempered glass door
- 24V Electric defogging
- **X LED Lighting stripes**
- Anti-theft design
- ※ Dimension: W116 × D83 × H194cm



Part I: Management system





1. System Login

1.1 Login link [for Smart phone]

https://moperator.tech.weimi24.com

1.2 Login link [for Computer]


https://operator.tech.weimi24.com/

1.3 Login

Input the User name and Password

How to upload/change the LOGO?

https://www.youtube.com/watch?v=W6jyQSCwHqI



Mobile phone Login page

Switch language

Computer Login page





Part I: Management system






2. Smart phone system

- **2.1** Device Management
- 2.2 Data Center
- 2.3 Order Center
- **2.4** Goods Management
- **2.5** *Energy Management

(Not available for some models)

- **2.6** Replanish Management
- **2.7** Monitor Center

*Follow to switch language and change password







Part I: Management system





3. Computor (PC) system

3.1 Operation Center


This module manages: Goods/Machine/ Advertising/Order/Replenishment

3.2 Monitoring Center

This module monitors the status of the machines: Online/Fault/Stockout/Abnormal; And see SIM Card and energy consumption

3.3 Data Center

This module, you can check the Sale report/trend/statistics/ranking



3.4 Member manage

This module manages the Member info, and funds

3.5 System manage

This module manages

Operator/IC card/Role/User





2.1.1 WIFI Connection (From machine LCD screen)

Connect a mouse to the USB port of the Android mainboard




Turn on Android

















2.1.2 Enter Vending APP





<u>Testing stage:</u>** Select Laucher3

<u>XAfter finished all settings:</u> Select APP-Laucher
(This step is very important!!!)

To make sure it will enter into the Vending App automatically.
















① Click " " to enter home page

Please enter the goods tray number

0/12



We call this as "Status bar" How to display or hide it? refer to next page










Tips: How to display/hide the status bar



<	Display	٩
	Brightness level Always hide the status	bar
1	Wallpaper	
	Screen orientation Reverse vertical screen	Tips:
	System Application	
	TP Orientation	① During testing period, please untick this ite to show the status bar at the bottom of screer
	Camera Orientation close	to onew the status bar at the bottom of corecin.
	Sleep Never	② After finished testing, please tick this item, to hide the status bar.
	Daydream	
	Font size Small	IMPORTANT!!!
	When device is rotated	
	Stay in current orientation	
	Cast screen	
	Screen Scale	








2.1.3 SIM Card (3G/4G)

In case WIFI is not available, you can insert a data SIM card.







The Andriod mainboard is installed at the back side of the screen. Insert the 3G/4G data SIM card into the card slot correctly as per the card direction guide sticker.

Restart Android (Green button).

Some SIM cards can access to internet automatically, while some can't, then need to set APN.







https://www.youtube.com/watch?v=ByIPLZGbuUw

2.1.3 SIM Card (3G/4G) If the data SIM card can access to internet, then <u>ignore</u> this step! If the SIM card can't access to internet, please follow this step to set APN (Access Point Names).

ettings	s & networks			٩
₩ ireles	Wi-Fi	*	More (I)	
0	Data usage		((1)	
Device			CK	
•	Home	Ψ	USB	•
0	Display		Sound & notification	
	Storage	•	Battery	
	Battery saver	•	Apps	
•	Users		ScreenshotSetting	
Person	tal			
9	Location	â	Security	
8	Accounts	#	Language & input	
۵	Backup & reset			
System				1
0	Date & time	Ť	Accessibility	
0	Printing	()	Developer options	
(1)	About device			


More 2Click "C	ellular networks"		Q
Airplane mode		()	
Tethering & portable hotspot			
Ethernet			
PPPoE			
VPN			
Cellular networks 2			
Ch			
Cellular network settings	③ Click "Access Point Names"		
		•	
Access Point Names 3			
	Airplane mode Tethering & portable hotspot Ethernet PPPoE VPN Cellular networks 2 Cellular network settings Data roaming Connect to data services when roaming Preferred network type LTE (recommended)	Airplane mode Tethering & portable hotspot Ethernet PPPOE VPN Cellular networks 2 Cellular network settings Connect to data services when roaming Preferred network type ITE (recommended) Access Point Names 3 Network operators	Airplane mode Tethering & portable hotspot Ethernet PPPoE VPN Cellular networks ② Cellular network settings ③ Click "Access Point Names" Preferred network type LTE (recommended) Access Point Names ③ Network operators








2.1.3 SIM Card (3G/4G) - Set APN



- 4 Click the " + " on the top right corner to create a APN;
- ⑤ Usually the mainboard can verify and show the MCC/MNC automatically. You only need to fill in the Name and APN. "Name" -- you can fill in whatever you like; "APN"-- you need to check with the SIM card provider or maybe you can find it from the internet.
- 6 Click the " on the top right corner to save APN; And then wait for the network connection, which may take 1~2 minutes.












2.2 Create product data base


Login management system by phone

https://moperator.tech.weimi24.com

Remark:

- We User name and Password will be sent to you by our sales person, please always keep it as confidential.
- ※ Product database can be created from both mobile and computer systems. However, we suggest do it from mobile system, as it is more convenient.
- ** The products you created can be used for ALL machines under this user name. No need to create products for each machine.









1




2.2 Create product data base





Optional:

Create product type. For future batch operation.



<	Goods_type	(微米物联
<u> </u>	Goods_type	MORON TED MODELOS
*Code:		
*Name:		
Regarks:		
	Submit (
	Submit	








2.3 Machine product set up

From Product database to each goods tray / slot










2.4 Fill the machine


Till here, machine is ready for Testing!

Physical Replenishment









*Shortcut:
Fill the whole floor/cabinet/machine









3.1 How to set temperature

Temperature controller

Ture on/off cooling system

For vending machine with cooling system.

The temperature can be adjusted Off set temp is 10°C (default).





How to set temperature?

https://www.youtube.com/watch?v=05RjsfNonu8(

Tips:

In case no Temp. controller is found there, then you can set the temperature from the Mobile phone system. (Energy module)









3.2 How to set currency symbol of selling price & set payment system

Smart phone system

Login Smart system with mobile phone

https://moperator.t ech.weimi24.com





Input the password "112233550077" on the machine screen













3.2 How to set currency symbol of selling price & set payment system












3.2.1 How to set currency symbol of selling price



Click "Currency symbol"

And then

Select the symbol

Besides, you can choose the position of the symbol before or behind the price "\$ 1.50" or "1.50 \$"










3.2.2 How to set payment system (based on the actual payment system)



Click "Card payment setting" to set the card readers;

Click "Payment by cash" to set the bill validator and coin machine; If it can refund small changes, then set the denominations [unit: cents]

Click "Turn on coin machine" to set the coin acceptor which accept coin only(not refund small changes);

Click "<u>Turn on coin changer</u>" to set the coin changer which refund coin only(not accept coins);

Click "Turn on QR code scanner" to enable payment by e-wallets;








3.3 How to set the time of entering advertisement page (from machine)

After you uploaded advertisement, when no one use the machine for a while, it will enter into advertisement page automatically. The default time will be 60s...And you can re-set the time from the machine screen.

on the keypad





Playing Ads










3.3 How to set the time of entering advertisement page (from machine)

Log in your mobile management system.









Input the password 112233550077 on the machine screen










3.3 How to set the time of entering advertisement page (from machine)

You can set the time as you like: input the number, and then click "confirm".

Input the password "112233550077" on the machine screen







		(tim	ne uni	e num t: seco	ond)	8
	dware vers	ion				
		frared Set the	time (s) of ente	ring advertiseme	nt p x e	
		Conte				
		efund		0		
		mfund	Co	nfie a		
			Clo	su 28		
Del	ivery mode	selection.	1	2	3	•
	7/2		100			
*	1	*	4	5	6	Done
()	=	7	8	9	
			*	0	#	
		a	7 0		3)	









3.4 How to hide status bar (from machine)



https://www.youtube.com/watch?v=aNeQR ClyHA





Before hide the <u>Status Bar</u>, please Select "App-launcher", so that it can go back Vending App from other page in 90s automatically.













How to hide status bar?

https://www.youtube.com/watch?v=aNeQR ClyHA

3.4 How to hide status bar (from machine)





Always hide the status bar

After finished setting, please tick this box to "always hide the status bar"

avoid confusion to the users









3.5 How to save coins to the coin machine (from machine)


www.youtube.com/watch?v= g5EBCHGN5c

How to save coins?

If your vending machines can return coins, please make sure there are enough coins inside the coin machine, to maintain the normal operation.



① Enter the passwork "112233550066" from the keypad, then it will switch from buying page to the coin setting mode.



② If the machine has <u>coin changer</u> only, you shall put the coins into the coin changer, and then enter this page as per step①, input the <u>number (not amount) of coins</u>, and Confirm.










3.6 How to check the Balance amount of the coins (from mobile)


Click "Device"



Choose the machine



Click "Device coin"



Click "Refresh"











3.7 How to amend the Capacity of the goods trays


Smart phone system

Login Smart system with phone

https://moperator.tech. weimi24.com

















3.8 How to set product shelf life date (Expiration) & warning (from mobile)

For those items (such as food) which shall be sold before a specific date, you can set the shelf life dates for the products when you put them to the shelf, and set warnings a few days before they expired.





















3.8 How to set product shelf life date (Expiration) & warning (from mobile)

After you set the dates, you will see the reminder as follow:












Part IV: Features dictionary





4.1 How to upload advertisement (PC system)



Login the system from your computer by User name/Password

PC Smart system

Login Smart system with Computer:

https://operator.tech.weimi24.com/





Part IV: Features dictionary






4.1 How to upload advertisement (PC system)

How to upload advertisements?

https://www.youtube.com/watch?v=BNJ49G07CmY













4.1 How to upload advertisement (PC system)

Cancel

Fill Ad information Upload advertisement to the system Add ad content * Ad placement 1 - Full screen (when no one use machine) Full screen (when no one use machine) * Ad SN 4 - Secondary screen (when machine has 2 screens) 2 - APP internal screen (when someone use machine) * Ad type Video AD Testing * Link address Upload video (MP4)

Uploaded advertisement should be:

- X Video (<20M/video)
 </p>
- ※ Photo(<2M/photo)</pre>
- ***** Words

For the machine with 5" screen,

Advertisement can be only

- Full screen (when no body buying)
- * The uploaded Ads can be released to all machines under the user name.








4.1 How to upload advertisement (PC system)

Machine Ad set up

Select the
 Ad_contents from
 database which was
 created in above step;

※ Release to all the machines, or aDesignated line, or aDesignated machine.









4.1 How to upload advertisement (PC system)



Playing Ads



Buying page

Press any key on the keypad







4.2 How to upload LOGO/ Service Tel. to the machine/ server


PC Smart system

Login Smart system with Computer:

https://operator.tech.weimi24.com



Input User name and password










4.2 How to upload LOGO/ Service Tel. to the machine/ server

Upload logo image and input service tel









4.2 How to upload LOGO/ Service Tel. to the machine/ server

You can change below logo to yours.

Logo on machine screen left top




Upload logo and service Tel. No.

www.youtube.com/watch?v=W6jyQSCwHqI&list=PLybk6qby1fLV4A5jbd9gYs5VI9DjXMCMy&index=8

Logo at mobile server



Logo at PC server









4.3 How to edit machine info. (PC system)

After you deployed the machine to a location for operation, you can edit the machine info., add the Machine name, Deployment location...

In this case, you can easily manage all the machines (especially when you have many machines), to avoid any confusion by just checking the device numbers.

Login the system from your computer by User name/Password











4.3 How to edit machine info. (PC system)




Machine list

You will see all the machines under your account.

Choose the machine that you need to edit from the list by its Machine ID.












4.3 How to edit machine info. (PC system)

X PC System

Choose the machine that you need to edit from the list by its Machine ID.

Click "Edit", and fill in the Machine name, and Deployment location.









4.4 How to set sub account for your team members (PC system)

For example: if you are an Operator, you have 20 machines, you want to create sub-accounts for 2 re-fillers, each of them manages 10 machines:

X 1. Create lines

①Line A, bind 10 machines;

②Line B, bind 10 machines;


% 2. Create Role

Role name: Re-filler;

Role description:

Role Permission: select from the list.

% 3. Add new user



Login the system from your computer by User name/Password









4.4 How to set sub account for your team members (PC system)


♠ Home

■ Operation center

% 1. Create lines Operation center ---> Machine manage ---> Line list ---> Add new line ---> Binding machine ①Line A, bind 10 machines; ②Line B, bind 10 machines; e.g. you can name the Lines with territories, such as City name/ District...and then bind

the machines according to the

machine deployed location.



Add new line					
SN	Code	Name	Remarks	Has deleted	Operation
1	002	City-B		Normal	Binding machine Edit Delete
dd new				×	Binding machine Edit Delete
* Code	Please input				
* Name	Please input				
Remarks	Please input				
* Data state	Normal				








4.4 How to set sub account for your team members (PC system)



Role name: Re-filler;

Role description:

Role Permission: tick the boxes, to allow the Role to see the relevant modules when they log in their accounts.



Tick the Permissions for PC system, and Mobile system respectively...








4.4 How to set sub account for your team members (PC system)

X 3. Add new user System manage ---> User list ---> Add new user ---> Bind Line

Select the Role of the

user...And then "Bind Line" for each user. Now, the new users can login the system, and manage those machines under each account.



You can create sub-accounts for your employees, such as Financial team/ purchasing team, etc...







4.5 How to set sub account for your customers (PC system)

For example: If you are a vending machine re-seller, you import machines from our company, all the machines are under your account.

When you sell out the machine(s) to each customer, you need to create sub account, and allocate machine(s) from your account to that customer (Agent), so that they can login and manage their own machine(s).

Login the system from your computer by User name/Password









4.5 How to set sub account for your customers (PC system)

3 Steps as follow:

Agent --->

Agent management

% 1. Add agent


Under your account, you can create sub accounts for all your customers.

% 2. Device binding

Bind the machine(s) by device number(s).

% 3. Configure

Do some basic settings...










4.5 How to set sub account for your customers (PC system)

**** Account setting**

After the sub account is created, login to the system by User name and default password 123456.

System_manage --->
Operator_info --->
Operator settings --->Edit

The account owner can upload Logo, input the Service Tel. No., change passwords, etc...










4.5 How to set sub account for your customers (PC system)

※ In case you need toSync product data base

After the sub account is created, login to the system by User name and password.

Operation center --->
Goods manage --->
Product data base

You can synchronize the product data base from a higher level operator to this new-created sub account.



Remark:

- ① Sub account can synchronize the product data base from a high-level operator only. It is not applicable in reverse.
- 2 After the product data base is synchronized, you can edit the info. freely, and add new products. If you synchronize it again, it will cover those products originated from last sync...However, it will not cover the new-added products.



♠ Home






4.6 How to use Member manage (PC system)

*If your machine is go with a card reader for membership cards (IC or ID card), please check this step.

 You need to list out all the IC card number (which is written on each card body), and the Reading Code of each card (which can be read by a card reader, or you can ask your card supplier to send it to you);

① PC System ---> System manage ---> IC manage ---> Import Excel










4.6 How to use Member manage (PC system)

2 PC System ---> Member manage ---> Member info ---> Add new member










4.6 How to use Member manage (PC system)

3 PC System ---> Member manage ---> Member info ---> Binding IC card










4.7 How to check Real time inventory

Smart phone system

Login Smart system with phone

https://moperator.tech.weimi24.com











4.7 How to check Real time inventory

Select the machine which you want to check.



Here you can check each product inventory











4.8.1 How to check Orders of all the machines

Smart phone system


Login Smart system with phone

https://moperator.t ech.weimi24.com





History order record












4.8.2 How to check orders of a single machine

















4.8.3 How to check Sales Data

Smart phone system

Login Smart system with phone

https://moperator.tech.weimi24.com













4.9.1 How to check Replenish record (PC system)

X 1. PC System

You can check the replenish record of ALL the machines under your account from PC system, by exporting the file in Excel format.

% 2. Mobile System

You can view the replenish record of ALL machines under your account, or you can just choose to view the record of a specific machine.

Login the system from your computer by User name/Password









4.9.1 How to check Replenish record (PC system)




Operation center --->

Replenish management

You can click "Export Excel file", and save the file to your computer, and then check all the details of all machines. Besides, you can input the Machine ID / Goods name/ Agent, and

Select date to <u>Search</u>.



■ Home / ■ Operation_center / ▼ Replenishment Manage Welcome:技术部测试 [] ● ■											
Home	 Replenishme 	ent Manage ×					>	(X			
Machine ID:	Please input	T .	Goods name:	Please input		Select date: Please select					
Agent: Selec	it	~	Search	Reset							
Export Exc	el file	1									
SN	Machine ID	Cabinet number	Shelf number	Goods name	Measure method	Replenishment quantity	Replenishment staff				
1	61260026	1	B11	default	Sale by piece	8					
2	61260026	1	B12	default	Sale by piece	8					
3	61260002	0	A4	default	Sale by piece	0					
4	61260002	0	A9	default	Sale by piece	0					
5	61260002	0	A2	Beef	Sale by piece	0					
6	61260002	0	A3	default	Sale by piece	0					
7	61260002	0	A5	default	Sale by piece	0					
8	61260002	0	A7	default	Sale by piece	6					
9	61260002	0	A1	Beef	Sale by piece	0					
	Home Machine ID: Agent: Select Export Exc SN 1 2 3 4 5 6 7	Home Replenishme Machine ID: Please input Agent: Select Export Excel file SN Machine ID 1 61260026 2 61260026 3 61260002 4 61260002 5 61260002 7 61260002 8 61260002	Home Replenishment Manage X Machine ID: Please input Agent: Select ✓ SN Machine ID Cabinet number 1 61260026 1 2 61260026 1 3 61260002 0 4 61260002 0 5 61260002 0 6 61260002 0 7 61260002 0 8 61260002 0	Home	Machine ID: Please input Goods name: Please input Agent: Select Search Reset SN Machine ID Cabinet number Shelf number Goods name 1 61260026 1 B11 default 2 61260026 1 B12 default 3 61260002 0 A4 default 4 61260002 0 A9 default 5 61260002 0 A2 Beef 6 61260002 0 A3 default 7 61260002 0 A5 default 8 61260002 0 A7 default	Aderine ID: Please input Goods name: Please input Agent: Select Search Reset SN Machine ID Cabinet number Shelf number Goods name Measure method name 1 61260026 1 B11 default Sale by piece 2 61260026 1 B12 default Sale by piece 3 61260002 0 A4 default Sale by piece 4 61260002 0 A9 default Sale by piece 5 61260002 0 A2 Beef Sale by piece 6 61260002 0 A3 default Sale by piece 7 61260002 0 A5 default Sale by piece 8 61260002 0 A7 default Sale by piece	Home	Home Replenishment Manage Replenishment Manage Replenishment Manage Reset Reset			









4.9.2 How to check Replenish record (Mobile system)

Login mobile system




Click "Replenish"



Click "Replenish record"



You will see the record for ALL machines under this account










4.9.2 How to check Replenish record (Mobile system)


Click "Device"



Choose the machine



Click "Replenish record"



You will see the record for the chosen machine only









5.1 Installation


5.1.1 Placement of the machine

Try to keep the machine away from following places:

- * direct wind/ rain/ sunlight;
- * high temperature/ humidity;
- * dusty places;
- * moisture or corrosive gas;
- * shaking or unstable ground;

5.1.2 Space for placing the machine

- * refer to the guidelines at the right side;
- * do not block the vents at the back of machine.










5.1 Installation

- 5.1.3 Well fixed the wheels of the machine to avoid any accidents from the movement;
- 5.1.4 Assist with a level ruler, make sure the machine is horizontally fixed on the ground.
- 5.1.5 If it is installed in the place with the possibility of tilting or rollover, it is necessary to install a fixed bottom plate;











5.2 Open the door lock (Type-1)

















5.2 Open the door lock (Type-2)













5.3 Electrical control

How to set temperature?

https://www.youtube.com/watch?v=05RjsfNonu8

Temperature control


Ture on/off cooling system

Ture on/off the door defog

Turn on/off Andriod system <

Leakage relay test button

Power on/off switch









5.4 Power supply

IMPORTANT: For safety purpose, please make sure the power supply has connected the grouding wire.

- * When the grounding wire is not connected, electric shock may occur.
- * In dry weather, the key components inside the machine are very likely to carry static electricity, which will cause the machine not work normally, or even get damaged.
- * Bad grounding will possibly lead to bad network signal as well.

5.5 Maintenance of leakage relay

Press the testing button at least one time a month to confirm the action of leakage relay. If no action, there is possibility of electric shock.



After testing...

Press down this button,

Turn on the power again.







5.6 Spiral coils angle adjustment

Pull out the spiral coil slightly (around 1CM), and then rotate the coil clockwise to the position that is suitable for the selling goods.

5.7 Direct-Push type goods tray

How to adjust the goods trays (direct push type)?

https://www.youtube.com/watch?v=ZW7j6gKYWkk

5.8 Fill products to machine

How to fill the goods to the machine?

https://www.youtube.com/watch?v=UMIxPMjN6F0













TOGETHER, LET'S STEP INTO THE NEW ERA OF UNMANNED RETAIL~

Guangzhou Micron Vending Technology Co., Ltd Your long-term smart vending machine supplier

Company address:

No.1, Tiantai 1st Road, Huangpu district 510700, Guangzhou, China.

Websites:

www.micronvending.com

www.automatic-vendingmachines.com

Youtube channel:

www.youtube.com/channel/UCCoR1uMn6lztRmoc7EmUFiQ/videos

Catalogue & User manual download

www.micronvending.com/en-download-vending-machine-catalog.html

